



marantz®

CD Player
CD5005

Quick Start Guide

Kurzanleitung

Guide de démarrage rapide

Guida all'avvio rapido

Guía de inicio rápido

Beknopte handleiding

Snabbstartsguide

Краткое руководство пользователя

Skrócona instrukcja obsługi

ENGLISH

DEUTSCH

FRANÇAIS

ITALIANO

ESPAÑOL

NEDERLANDS

SVENSKA

РУССКИЙ

POLSKI

Welcome

Thank you for choosing a Marantz CD player. This guide provides step-by-step instructions for setting up your CD player.

Please do not return this unit to the store – call for assistance.

If you need help... :

If you need additional help in solving problems, contact Marantz customer service in your area.

For details, see the Marantz homepage. www.marantz.com

Before You Begin

What's In the Box


Quick Start Guide	

Setup


There are five steps to the setup process.

- 1** Install batteries in the remote control unit
- 2** Connect the CD player to the amplifier
- 3** Plug the power cord into a power outlet
- 4** Turn the CD player's power on
- 5** Begin CD playback


1 Install batteries in the remote control unit




2 Connect the CD player to the amplifier



3 Plug the power cord into a power outlet



4 Turn the CD player's power on



5 Begin CD playback




Owner's Manual

❑ Web Manual

To read it on your tablet or PC, please access to Web Manual site.

manuals.marantz.com/CD5005/EU/EN




❑ PDF Manual

To read the owner's manual on your computer or to print it out, please open the included CD-ROM or select the "PDF Download" link from the Web Manual.

1

Insert the disc into your PC.



2

Follow the screen or double click on the PDF file.

www.marantz.com

You can find your nearest authorized distributor or dealer on our website.

marantz[®] is a registered trademark.

D&M Holdings Inc.
Printed in China 5411 11171 00AM