



marantz®

Integrated Amplifier **PM5005**

Quick Start Guide

Kurzanleitung

Guide de démarrage rapide

Guida all'avvio rapido

Guía de inicio rápido

Beknopte handleiding

Snabbstartsguide

Краткое руководство пользователя

Skrócona instrukcja obsługi

ENGLISH

DEUTSCH

FRANÇAIS

ITALIANO

ESPAÑOL

NEDERLANDS

SVENSKA

РУССКИЙ

POLSKI

Welcome

Thank you for choosing a Marantz amplifier. This guide provides step-by-step instructions for setting up your amplifier.

Please do not return this unit to the store – call for assistance.








If you need help... :

If you need additional help in solving problems, contact Marantz customer service in your area.

For details, see the Marantz homepage. www.marantz.com

Before You Begin

What's In the Box

Quick Start Guide		Power cord	
Owner's Manual		Remote control unit	
Safety Instructions		R03/AAA batteries	
Amplifier			



These drawings are for illustrative purposes only and may not represent the actual product(s).

Setup

There are six steps to the setup process.

1 Install batteries in the remote control unit

2 Connect the speakers to the amplifier

3 Connect the CD player to the amplifier


4 Plug the power cord into a power outlet

5 Turn the amplifier's power on


6 Begin playback

1

Install batteries in the remote control unit



2 Connect the speakers to the amplifier




Connecting the speaker cables


- ① Peel off about 10 mm of sheathing from the tip of the speaker cable, then either twist the core wire tightly or apply solder to it.
- ② Turn the speaker terminal counterclockwise to loosen it.
- ③ Insert the speaker cable's core wire to all the way into the speaker terminal.
- ④ Turn the speaker terminal clockwise to tighten it.




3 Connect the CD player to the amplifier





4 Plug the power cord into a power outlet



5 Turn the amplifier's power on




6 Begin playback



1 Set the input source to “CD”.

2 Play the CD player.



3 Adjust the volume.

❑ PDF Manual

To read the owner's manual on your computer or to print it out, please open the included CD-ROM or select the "PDF Download" link from the Web Manual.

**Insert the disc into
your PC.**



www.marantz.com

You can find your nearest authorized distributor or dealer on our website.

marantz[®] is a registered trademark.

D&M Holdings Inc.
Printed in China 5411 11176 00AM